



Internal Shading Instruction Manual



Made in the United Kingdom

Please read all instructions before proceeding

Internal Shading Installation

To install the internal shading blinds to your Alton Victorian greenhouse you will need to temporarily remove the ridge spandrels to give yourself more room. With the brackets removed you will be able to position the roller blind parallel to the underside of the ridge. Fix this in place with round head screws.



Where a roller blind meets a gable end you will need adjust the direction of the flange. Using an adjustable spanner clamp this onto the flange with the fixing hole in and bend it upwards. You will now be able to fix this inline with the other blinds.

With all the blinds in place you can re-attach the spandrels. You will see they slot neatly over the fixing brackets of the blinds.

Internal Shading Installation

The blind hooks need to be mounted as shown below, either onto the eaves spandrel or just above the gable end purling's.





Alton Greenhouses, TGP Ltd, Blythe Park, Cresswell, Stoke-on-Trent, ST11 9RD

Telephone: 01782 385 409 www.Altongreenhouses.co.uk sales@altongreenhouses.co.uk